

## Advantages Of Water Filter Pitcher

- Creates silky-smooth and great tasting water that is refreshing to drink and cook with.
- Helps filter out chlorine and other contaminants and permanently absorbs metals such as lead and copper, so your drinking water will be more refreshing and clear.
- Reduces lime scale, prolong the domestic appliance life by preventing limescale.
- Increases active hydrogen.
- Offers pH 8.5-10.0 to help support systemic pH balance in the body. (Typically increases pH by 2 or more points).
- Provides low negative ORP:-100mv. This transforms ordinary water into rich antioxidant water to help energize and revitalize your body.
- Reduces water molecule size to create more absorbable water and increase hydration.
- Increases the alkalinity to make your drinking water more vital.



4 colors are available

## Components

- "Smart" digital indicator
- Lid
- Funnel reservoir
- Replaceable filter cartridge
- Pitcher with measuring scale



## Technical Specifications

- "Smart" digital indicator show cartridge life
- Streamlined contemporary design with contoured handle-easy to lift and pour
- Pitcher capacity: 3.5L
- Filtration capacity: 2L
- Cartridge life: 300 litres water (saving purchase of bottled drinking water)
- Pitcher material: AS
- Lid, funnel and handle material: ABS
- Cartridge housing material: PP
- Cartridge Media: Active Carbon, Ion Exchange Resin, Negative Potential Particles, Natural Bio Minerals
- Gross weight: 980 g (2.16 lbs)
- Size: 26.5 cm (H) x 28 cm (W) x 13 cm (D)



## WATER FILTER PITCHER

FOR INFORMATION OR QUESTIONS ON ANY OF WATER  
FILTER PITCHER & ACCESSORY, PLEASE CONTACT

WEBSITE

[www.GreenPalStore.com](http://www.GreenPalStore.com)

[www.GreenPalStore.com](http://www.GreenPalStore.com)

[www.GreenPalStore.com](http://www.GreenPalStore.com)

## How To Program The Electronic Cartridge Life Indicator

- 1.1 Press the button and hold it down for a few seconds until the symbols appear on the screen. Once you release the button, the blinking symbol of users appears on the screen.
- 1.2 Now you can set the number of users by pressing the button. Press the button twice quickly, then press the button to choose the user number, release the button until the desired number of users appears on the display.
- 1.3 Once you set the number of users, press the button and hold it down for several seconds until the symbol of the cartridge appears on the display. The indicator is now activated.

Note: The indicator switches off if the button is not pressed within 30 seconds before the timer is programmed. If this occurs, please repeat the steps 1.1-1.3




Fig 1



Fig 2




Fig 3




Fig 4




Fig 5




Fig 6

### Knowing when to replace the filter cartridge

When the blinking warning symbol ("X") appears on the cartridge image in the display, it means that the filter cartridge should be replaced within one week. As the week passes all symbols on the screen start blinking reminding you that filter cartridge life has expired. Replace the filter cartridge at this time.

Remarks: The filter service as follow: 1 user 80 days, 2 users 60 days, 3 users 40 days, 4 users 30 days

## Instructions & Easy Set Up Guide

- 2.1 Clean the funnel reservoir and pitcher in the dishwasher or by hand using a mild detergent.
- 2.2 The lid MUST NOT be washed in the dishwasher. Clean the lid with a soft damp cloth by hand.
- 2.3 Remove the filter from its package and soak the cartridge in cold water for 15 minutes. Then screw the cartridge firmly into the base of the funnel reservoir.
- 2.4 Place the funnel reservoir into the top of the pitcher.
- 2.5 Fill the funnel reservoir with cold water and wait until the water in the funnel reservoir has filtered into the pitcher.
- 2.6 Please allow up to 15 minutes for the water to filter through to clean and activate the filter cartridge. Discard this water. Repeat step 2.5 twice to rinse away any loose activated carbon particles and prepare the new cartridge for using.
- 2.7 When filling the alkaline antioxidant water pitcher, do not place the filter cartridges opening directly under the running water.
- 2.8 The pitcher should periodically be cleaned with mild soapy water and dry with a soft cloth. Please ensure that the filter cartridge is removed prior to cleaning.
- 2.9 In order to preserve the life of the filter cartridge, it should always stay in contact with water, so we suggest the pitcher is filled overnight and the water discarded in the morning.

### Easy set up Guide

- 3.1 Remove used cartridge from the filter reservoir and discard it with your regular waste. Clean pitcher, funnel and lid with a mild detergent in warm water resin thoroughly.
- 3.2 Remove foil from the replacement cartridge and soak the cartridge in cold water for 15 minutes.
- 3.3 Screw the replacement cartridge into the funnel.
- 3.4 Fill the funnel with water, let it filter then empty it. Repeat this operation once or twice.
- 3.5 The water filter pitcher is now ready for use.



## How To Replace The Filter Cartridge

- 4.1 Unscrew the used filter cartridge from the base of the funnel reservoir and discard.
- 4.2 Rinse the pitcher parts carefully.
- 4.3 Screw the new filter cartridge into the base of the funnel reservoir and repeat steps 2.1-2.5 of set up guide.
- 4.4 Keep your new replacement cartridges in their original packaging until use and store in a dry, cool place.
- 4.5 The filter cartridges should be replaced every 200-300 litres or every 6-8 weeks of regular daily use.
- 4.6 Re-set and re-activate the indicator as before. You can easily change the number of users by entering the users' setting mode: quickly double press the button, then repeat steps 1.2 and 1.3. When the number of users changed, the cartridge life is recalculated automatically.

### Notice

- 5.1 Do not pour carbonated drinks, milk, coffee, tea or other similar liquids into the alkaline water pitcher when the cartridge is in place. Doing so may reduce or destroy the cartridge filter properties.
- 5.2 Do not use in the microwave or heat on a stove. Please store in a cool, dry place.
- 5.3 If you are not accustomed to alkaline water, please go slowly in order to allow time for your body to adjust.
- 5.4 Do not use the alkaline water for infant or little child.
- 5.5 Patients with heart issues, allergy and stomach problems should consult with their physician before using the alkaline water filter pitcher.
- 5.6 If any unusual symptoms or heavy detox symptoms arise please stop using and consult your physician.
- 5.7 Replacement water filter cartridges are available from the Green Pal Store.

[www.GreenPalStore.com](http://www.GreenPalStore.com)